





Model 1

Connections & Specifications

- | | | |
|---------------------------|--------------|----------------|
| 1 = PANA Rec Start/Stop | 6 = Ground | 11 = LANC Data |
| 2 = PANA Zoom | 7 = 422 TX+ | 12 = 232 TX |
| 3 = PANA Iris Auto/Manual | 8 = 422 TX- | 13 = 232 RX |
| 4 = PANA Iris | 9 = 422 RX+ | 14 = none |
| 5 = PANA Focus | 10 = 422 RX- | 15 = none |



Tilt Plate Dimensions



3.75" (9.5cm)

5.75" (14.6cm)

6.00" x 6.00" (15.2cm)
7.5 lbs (3.4kg)


4" (10.2cm)



Model 2

Connections & Specifications

- | | | |
|---------------------------|--------------|----------------|
| 1 = PANA Rec Start/Stop | 6 = Ground | 11 = LANC Data |
| 2 = PANA Zoom | 7 = 422 TX+ | 12 = 232 TX |
| 3 = PANA Iris Auto/Manual | 8 = 422 TX- | 13 = 232 RX |
| 4 = PANA Iris | 9 = 422 RX+ | 14 = none |
| 5 = PANA Focus | 10 = 422 RX- | 15 = none |



Controller

Camera


DMX

- VISCA
- LANC
- Panasonic REMOTE

VISCA

- VISCA
- LANC
- Panasonic REMOTE

Tilt Plate Dimensions



7.25" (18.4cm)

9.00" (22.9cm)

9.00" x 11.00" (22.9 x 27.9cm)
22 lbs (10kg)

MODE SWX DMX/VISCA ID SWX

7.5" (19cm)

7.0" (17.8cm)



888.894.7874